

- Footswitch connector: Not specified
- Number of switches: 2
- Expression pedal: no
- MIDI & CV/gate: none
- Type of switch(es): latched
- Universal foot switch: no, foot switch for specific product
- Fixed cable: no